

Smart Panel Light

























1. Smart control 🏟





Connect bluetooth and WIFI to control the lights



Voice control

Works with the Amazon Alexa, Google Home, just make a voice command to control the light.



Remote control

Download the "Tuya Smart" APP. Via Wi-Fi or Bluetooth. You can remotely control the lights through the app.



Group Control

You can create groups for your smart lights so that you can switch them on and off with just one command at the same time.



2. APP remote control

- Tuya smart APP control
- DIY the Color
- CCT adjustment
- Brightness adjustment



Download Tuya Smart APP

16 Million Colors




Warm White to Daylight

+86-755-2760 8650




Scene simulation





Signcomplex | light and smart

Bottom of the back cover is produced by stamping structure, which can effectively guarantee the appearance of the product. The surface is processed by electrostatic dusting.



Energy-saving percentage (compared with traditional type) With energy savings of up to 90% than incandescent light

Application


Suitable for hotels, meeting rooms, factories, offices, commercial purposes, residential, institution buildings, schools, hospitals, etc.





Parameter


Model	Color	Power (W)	CCT	Luminous flux	Power	Beam angle	IP grade	Input voltage	LED type	CRI	PF
	White	36W	6000-6500K								
SC-PSC24CCT-RGB595	Warm white	36W	3000-3300K								
*595-36W	Red	5W		100lm/W	36W	110°	IP40	220-240VAC/	2835	≥80	>0.9
SC-PSC24CCT-RGB295	Green	4.5W						50/60HZ			
*1195-36W	Blue										
	RGB	7W									






Installation drawing

1. Drill Holes




• Move away the plasterboard of corresponding size

2. Wiring




- Brown wire connects with L and blue wire connects with N
- Note: please ensure that the wires are connected right and provide insulation treatment.

3. Put the lamp into the ceiling



- Insert DC male head into DC female head and tighten them.
- Note: first, insert DC male head into DC female head and tighten them, then put the lamp

Wiring diagram



Installation instruction

- Power off before installation.
- Ensure that the installed object can bear the lamp weight. Open the groove on the ceiling according to corresponding size. Then install the lamp into the clamping groove on the ceiling.
- Then connect wire attached to the lamp onto the corresponding power cord and carry out insulation sealing at the joint.



Package information

Model	Net weight/lamp	Gross weight/inner box	Inner box size	Carton size	Gross weight/carton	PCS
595*595	1.8kg	2.3kg	650*50*650MM	675*275*675MM	12.5kg	5pcs
295*1195	1.85kg	2.4kg	330*1250*50MM	1275*275*355MM	12.8kg	5pcs

Notice

- Please read the specification first, to make sure the service environment matches the condition in the specification before using;
- Please confirm the input voltage and frequency before using;
- The light must be installed by professional;
- If power wire or shell of the light is damaged, the light is unqualified and can't be used;
- Dangerous high voltage, non-professionals are not allowed to maintain the products;
- If the exterior soft cable or wire is damaged, it must be exchanged by the manufacturer, its agent or other similar qualified personnel to avoid dangers.